



MULTICHROME

APPLICATION GUIDE

Multichrome can be applied with almost any type of spray equipment from airbrushed to full size HVLP guns. Multichrome comes ready to spray meaning no reducers or hardeners, just pour it in your gun and spray. When you're finished simply pour it back into its container to use later.

Multichrome can be used on any surface you can paint such as metals, plastics, wood, foams etc. From trim pieces and logos to full blown custom paint jobs, the possibilities are endless.

Multichrome will create a mirror finish as long as your surface is as smooth as glass and a prismatic color will burst when viewed from different angles.

Steps:

1. Apply Alsa's Jet Black Stylin' Basecoat ASB-13
2. Allow to dry for 30-60 minutes before applying the recommended Alsa Speed Clear SC1230
3. Let the Speed Clear SC1230 dry overnight.
4. Apply 2-3 dust coats of Multichrome at 25 PSI with an IWATA LPH50 (or equivalent gun) with a 1.0 Fluid Tip, apply one coat after the other then allow the Multichrome to sit overnight in a clean area at 77°F.
5. Clear with the recommended Alsa Speed Clear SC1230.